



This application note describes the general working and configuration of the Suprema Fingerprint Scanner possibilities with EasyConf



# Suprema Fingerprint Scanner

With **EasyConf** you can use the **Suprema Fingerprint Scanner** solution to identify and login delegates to conference units.

This application note explains how to configure and use **Suprema Fingerprint Scanners** with **EasyConf**.



#### Install BioStar 2 software

First of all, install the Suprema BioStar 2 software as described in their manuals.





### **Open BioStar 2 software**

Open the BioStar 2 software using the shortcut on your desktop, or enter <u>https://127.0.0.1</u> in your browser to open the web interface.

Please login using the credentials you defined during the installation of the BioStar 2 software.





#### **Devices**

BioStar 2 dashboard will open, please go to the **Device** page to continue.





#### **Search for devices**

At the **Device** page, click **SEARCH DEVICE** to automatically search for fingerprint scanners available on the network.

When devices are found, select de device you want and click **Add** to continue.





#### Advanced search for devices

At the **Device** page, click **ADVANCED SEARCH** to manually search for fingerprint scanners on the network by entering the **IP address** of the Fingerprint scanner you want to add.

When you find the device, select the device and click **Add** to continue.

BioStar 2     ×     +       ←     →     C* <b>© ▲</b> ~• h	ttps:// <b>127.0.0.1</b> /#/device/list?timestamp=	1594387563409		··· 🛛 🏠 🔍	Advanced Sea	rch			×
BioStar 2 🛞 Settings 🖧 Port ()	About () Help								
All Devices	All Devices			Device	Device ID	Name	Group	Device Type (Master/Slave)	IP Address
BioEntry W2 544191012 (19.	Device ID     544191012     Bio	Name 2Entry W2 \$44191012 (192.168.201.67)	Group	(Master BioEntry W2	544191012	BioEntry W2 544191012 (192.168	All Devices	BioEntry W2	192.168.201.67
USB Device		Advanced Search		×					
		IP Address     192.     Device Port     5121	168.201.67		Search			Add	Cancel
			Search Cancel						



#### **Create user**

At the **User** page, click **ADD USER** to create a new user. A user will later be used to link a fingerprint to a specific user in **EasyConf**. We suggest to use the delegate names.





#### **Create user**

Enter at least a username at the **Name** field. All other fields are not mandatory.

Click **+ Fingerprint** to add a fingerprint for a user. This can also be done later.

BioStar 2	× +						- σ
(←) → C <sup>2</sup> f	û 🛛 🔒	- https://127.0.0.1/#/us	er/detail/		▽ ☆	Q. Zoeken	III\ 🗉 🤨 🎕
BioStar 2	🕲 Settings 🖧 Port	🕜 About ⊘ Help					Administrator
CT DASH BOARD	← Add New Us	ser					
R	Information						
		• Name			• Email		
		• ID	3		<ul> <li>Telephone</li> </ul>		
DOON	$\frown$	Group	All Users	Ŧ	Status	C Active	
		Period	2001/01/01 00:00 ~ 2030/12/31 23:59				
CONTROL	+ Add Photo	Operator Level	None	Ŧ	Access Group		¥
		Login ID			USER IP		
0		Password					
ATTENDANCE	Credential						
	• 🗌 PIN						
	Auth Mode	Device Default					
	Credential	+ Fingerprint	Face 🕒 + Card 🖬				
	1:1 Security Level	•	Device Default				
							Apply Cancel



## Add fingerprint

Select the device you want to use to add a new fingerprint to a user.





### Add fingerprint

Click the **+** Add button to add a new finger in the system.

Click the **scan** button to start scanning the fingerprint.

Follow the instructions on screen.

Enroll Fingerprin	t		×
Device	BioEntry W2 544	4191012 (192.168.201	.67) 💌
• Quality	Please place	the 1st finger on the	sensor.
Enroll Finger	print		
1st + Add			Scan Delete Validate
		5 0 0 0 0 0 0 0 0	Duress
	Enroll	Cancel	



## Add fingerprint

When the fingerprint is scanned correct, click **Enroll** to continue.





### Activate fingerprint identification in EasyConf

- In EasyConf go to Settings, Conference settings.
- Click Enable Identification.
- Select Use Suprema BioStar 2 API.
- Enter the correct credentials and port number.
- Restart the **EasyConf** software to apply the changes.

	MVI voting and control server					
	File Configuration Profiles	admin				
	Settings Meeting Preparation	Persons/Groups				AudioVisual
	NG-CCU2 Connected API: 0 Connected	cted Clients: 2   12	7.0.0.1:52453 864,757	1		
🖓 Generic settings, speech time and Touch temple	ite selection					
Generic settings Template selection Confe	rence settings Default meeting va	alues Multi Site/	Remote Seats serv	er MetadataInterface	Conference System Se	ettings
Allow metadata XML to additionally be st Warning: This will require more disk-space	over time	2	uprema Fingerprint Enable Identificatio O Use Suprema I	/NFC identification on (change requires res Database (old method)	tart of software)	
Allow ID cards to be overwritten when inp Support import of XML meetings in meeting	ort Excel files.		localhost\BS	SERVER	Fingerprint database	
	gproperation		BioStar		Fingerprint initial table	
Allow agenda and vote start during pre-me	eting start		Use Suprema b	biostar 2 API (new met	nod)	
Voting list follows active agenda			192.168.201.2	7	Server address	
			443 😨	Server Http(s) port	Use Https	
			******		] User Password	
					]	
Default Values		Default Va	lues			
Z Amo	unt of voting answers	{1} {2} {3}		Print Line dele	gates in lists	
Votir	ng template	{1} {2} {3}		Print Line dele	gates in seats	
Open		{1} {2} {3}		Camera line 1	(usually a persons name)	
Open V Disc	ussion Template	{4}		Camera line 2	(usually a persons title)	
Disc	ussion Template Stop Meeting			Camera line 3		
				Camera line 4		
		PrintLine: Us. {1) = First Na {2} = Middle {3} = Last Na {4] = Title {5] = Country {6] = Group/ {7] = Current {8] = Current Example: {4]	e the following options to me me Region Meeting Tele Meeting Agenda (1) (2) (3) from (5)	create the name:		



### Activate fingerprint identification in EasyConf

name Adminis Alexano

Get pers

Import Bosch

#### In EasyConf go to Persons/Groups.

At Bosch Fingerprint Users click Get person list to import the user list with fingerprints from the BioStar 2 software.

					💛 MVI voti	ing and con	trol server						- 0	
					File Co	nfiguration	Profiles admin							
						2	<b>1</b>						ſ	IJ
😗 All pers	ons/delegates/gro	oups			Settings	Meeting F	Preperation Persons	Groups	_				Audio	Visu
Delegates	Groups				NG-CCU2	Connected A	API: 0 Connected Clier	hts: 2   127.0.0.1:52	972 866,7416					
FirstNar	ne	MiddleName	LastName	Title	(	Country	GroupName	CardCode	FingerprintId	NFCidstring2	^	Bosch Fingerprint us	ers	
Admin			Admin					0	0					
api			арі					0	0					
Synoptic			Synoptic					0	0					
Lucas			Dupont				France	0	0					
Jules			Foumier				France	0	2					
Camille			Durand				France	0	0					
Frederiqu	e		Martinez				France	0	0					
Feline			Bonnet				France	0	0					
Alina			Yilmaz				France	0	0					
Claudia			Schulz				Germany	0	0			G	et person list	
Elisabeth			Hoffmann				Germany	0	0					_
Adam			Müller				Germany	0	0			Import B	osch user map	ping
Bernd			Schneider				Germany	0	0					
Martha			Weber				Germany	0	0					
Stanley			Sardjoe				Germany	0	0					
Petra			Becker				Germany	0	0					
Dewi			Lu				The Netherlands	0	0					
Albertine			Bakker				The Netherlands	0	0					
Gerard			Dijkstra				The Netherlands	0	0			Delegate photo		
Stephan	e		Mulder				The Netherlands	0	0					
Jan			Vos				The Netherlands	0	0			XX XX		
Karel		van	Leeuwen				The Netherlands	0	0					
Ely		de	Wit				The Netherlands	0	0				Carda	
Henk		de	Groot				The Netherlands	0	0				modificatio	ons to
Marian			Vermeulen				The Netherlands	0	0		~		clients and	d API
EasyCor Maximu	nf Connect m allowed remote p	articipants for t	his room: 200							Delegate control				
Op invita selecte	en email tion form for ad delegates	enerate single invitation file	Generate all invitation files							+ Remo	ove all n	ot part of a meeting	Remove	all



### Link fingerprint to a user in EasyConf

In both lists select the delegate you want to link to a fingerprint.

Click the 🗲 button to link the fingerprint to the selected user.

You can now login to a seat using the fingerprint scanner whe na meeting is running.

0 0 0 2 0 0 0 0 0 0 0 0 0 0 0 0 0				id 1 // 2 // G Import B	name Administrator Alexander et person list osch user mapp
0 0 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0				1 / / 2 / / G Import B	Administrator Alexander iet person list osch user mapp
0 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0				2 / G Import B	Alexander iet person list osch user mapp
0 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0				G Import B	iet person list osch user mapp
2 0 0 0 0 0 0 0 0 0 0 0 0 0				G Import B	iet person list osch user mapj
0 0 0 0 0 0 0 0 0 0 0 0				G Import B	iet person list losch user map
0 0 0 0 0 0 0 0 0 0 0				G Import B	et person list losch user map
0 0 0 0 0 0 0 0				G Import B	et person list losch user map
0 0 0 0 0 0 0				G Import B	iet person list losch user map
0 0 0 0 0 0				G Import B	iet person list losch user map
0 0 0 0 0				Import B	losch user map
0 0 0 0				Import B	losch user map
0 0 0					
0					
0					
0					
0					
0			Delegate	abata 🗙	1
0			Delegate	photo 🔨	1
0					
0			100		
0			02	5	
0			133	1	Send a
0					modificatio
0		~		77 16	Cilents an
	0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0     Delegate photo       0     O